

Backdoor, Endianness, x86-64

Spring Break!



CS 2130: Computer Systems and Organization 1
February 27, 2026

Announcements

- Homework 4 **due Monday after break** on Gradescope
 - You have written most of this code already
 - Lab 7 may provide a fast way to get started
- Regrade requests for midterm 1 due Friday after break


Our Hardware Backdoor

Our exploit will have 2 components

- Passcode: need to recognize when we see the passcode
- Program: do something bad when I see the passcode

Backdoor will recognize and run

Our Hardware Backdoor



Ethics, Business, Tech

Are there reasons to do this? Not to do this?

- No technical reason not to, it's easy to do!

Ethics, Business, Tech

Are there reasons to do this? Not to do this?

- No technical reason not to, it's easy to do!
- Ethical implications
- Business implications (lawsuits, PR, etc)

Ethics, Business, Tech

Are there reasons to do this? Not to do this?

- No technical reason not to, it's easy to do!
- Ethical implications
- Business implications (lawsuits, PR, etc)

Can we make a system where one bad actor can't break it?

Ethics, Business, Tech

Are there reasons to do this? Not to do this?

- No technical reason not to, it's easy to do!
- Ethical implications
- Business implications (lawsuits, PR, etc)

Can we make a system where one bad actor can't break it?

- Code reviews, double checks, verification systems, automated verification systems, ...

Why does this work?

Why?

Why does this work?

- **It's all bytes!**
- Everything we store in computers are bytes
- We store code and data in the same place: memory

It's all bytes

Memory, Code, Data... It's all bytes!

- **Enumerate** - pick the meaning for each possible byte
- **Adjacency** - store bigger values together (sequentially)
- **Pointers** - a value treated as address of thing we are interested in

Enumerate

Enumerate - pick the meaning for each possible byte

What is 8-bit 0x54?

Unsigned integer

Signed integer

Floating point w/ 4-bit exponent

ASCII

Bitvector sets

Our example ISA

eighty-four

positive eighty-four

twelve

capital letter T: T

The set {2, 3, 5}

Write to memory: $M[r0] = r1$

Adjacency

Adjacency - store bigger values together (sequentially)

- An array: build bigger values out of many copies of the same type of small values
 - Store them next to each other in memory
 - Arithmetic to find any given value based on index

Adjacency

Adjacency - store bigger values together (sequentially)

- Records, structures, classes
 - Classes have fields! Store them adjacently
 - Know how to access (add offsets from base address)
 - If you tell me where object is, I can find fields

Pointers

Pointers - a value treated as address of thing we are interested in

- A value that really points to another value
- Easy to describe, hard to use properly
- *We'll be talking about these a lot in this class!*

Pointers

Pointers - a value treated as address of thing we are interested in

- Give us strange new powers (represent more complicated things), e.g.,
 - Variable-sized lists
 - Values that we don't know their type without looking
 - Dictionaries, maps

Programs Use These!

How do our programs use these?

- Enumerated icodes, numbers
- Adjacently stored instructions (PC+1)
- Pointers of where to jump/goto (addresses in memory)

ToyISA Instructions

So far, only dealing with 8-bit machine!

icode	b	meaning
0		$rA = rB$
1		$rA \&= rB$
2		$rA += rB$
3	0	$rA = \sim rA$
	1	$rA = !rA$
	2	$rA = -rA$
	3	$rA = pc$
4		$rA = \text{read from memory at address } rB$
5		write rA to memory at address rB
6	0	$rA = \text{read from memory at } pc + 1$
	1	$rA \&= \text{read from memory at } pc + 1$
	2	$rA += \text{read from memory at } pc + 1$
	3	$rA = \text{read from memory at the address stored at } pc + 1$ For icode 6, increase pc by 2 at end of instruction
7		Compare rA as 8-bit 2's-complement to 0 if $rA \leq 0$ set $pc = rB$ else increment pc as normal

64-bit Machines

64-bit machine: The **registers** are 64-bits

- i.e., `r0`, but also `PC`

Important to have large values. Why?

64-bit Machines

64-bit machine: The **registers** are 64-bits

- i.e., `r0`, but also `PC`

Important to have large values. Why?

- Most important: `PC` and memory addresses
- How much memory could our 8-bit machine access?

64-bit Machines

64-bit machine: The **registers** are 64-bits

- i.e., `r0`, but also `PC`

Important to have large values. Why?

- Most important: `PC` and memory addresses
- How much memory could our 8-bit machine access? **256 bytes**

64-bit Machines

64-bit machine: The **registers** are 64-bits

- i.e., `r0`, but also PC

Important to have large values. Why?

- Most important: PC and memory addresses
- How much memory could our 8-bit machine access? 256 bytes
- Late 70s - 16 bits:

64-bit Machines

64-bit machine: The **registers** are 64-bits

- i.e., `r0`, but also PC

Important to have large values. Why?

- Most important: PC and memory addresses
- How much memory could our 8-bit machine access? 256 bytes
- Late 70s - 16 bits: 65,536 bytes

64-bit Machines

64-bit machine: The **registers** are 64-bits

- i.e., `r0`, but also PC

Important to have large values. Why?

- Most important: PC and memory addresses
- How much memory could our 8-bit machine access? 256 bytes
- Late 70s - 16 bits: 65,536 bytes
- 80s - 32 bits:

64-bit Machines

64-bit machine: The **registers** are 64-bits

- i.e., `r0`, but also PC

Important to have large values. Why?

- Most important: PC and memory addresses
- How much memory could our 8-bit machine access? 256 bytes
- Late 70s - 16 bits: 65,536 bytes
- 80s - 32 bits: \approx 4 billion bytes

64-bit Machines

64-bit machine: The **registers** are 64-bits

- i.e., `r0`, but also PC

Important to have large values. Why?

- Most important: PC and memory addresses
- How much memory could our 8-bit machine access? 256 bytes
- Late 70s - 16 bits: 65,536 bytes
- 80s - 32 bits: \approx 4 billion bytes
- Today's processors - 64 bits:

64-bit Machines

64-bit machine: The **registers** are 64-bits

- i.e., r0, but also PC

Important to have large values. Why?

- Most important: PC and memory addresses
- How much memory could our 8-bit machine access? 256 bytes
- Late 70s - 16 bits: 65,536 bytes
- 80s - 32 bits: ≈ 4 billion bytes
- Today's processors - 64 bits: 2^{64} addresses

Aside: Powers of Two

Powers of Two

Value	base-10	Short form	Pronounced
2^{10}	1024	Ki	Kilo
2^{20}	1,048,576	Mi	Mega
2^{30}	1,073,741,824	Gi	Giga
2^{40}	1,099,511,627,776	Ti	Tera
2^{50}	1,125,899,906,842,624	Pi	Peta
2^{60}	1,152,921,504,606,846,976	Ei	Exa

Example: 2^{27} bytes

Aside: Powers of Two

Powers of Two

Value	base-10	Short form	Pronounced
2^{10}	1024	Ki	Kilo
2^{20}	1,048,576	Mi	Mega
2^{30}	1,073,741,824	Gi	Giga
2^{40}	1,099,511,627,776	Ti	Tera
2^{50}	1,125,899,906,842,624	Pi	Peta
2^{60}	1,152,921,504,606,846,976	Ei	Exa

Example: 2^{27} bytes = $2^7 \times 2^{20}$ bytes

Aside: Powers of Two

Powers of Two

Value	base-10	Short form	Pronounced
2^{10}	1024	Ki	Kilo
2^{20}	1,048,576	Mi	Mega
2^{30}	1,073,741,824	Gi	Giga
2^{40}	1,099,511,627,776	Ti	Tera
2^{50}	1,125,899,906,842,624	Pi	Peta
2^{60}	1,152,921,504,606,846,976	Ei	Exa

Example: 2^{27} bytes = $2^7 \times 2^{20}$ bytes = 2^7 MiB = 128 MiB

64-bit Machines

How much can we address with 64-bits?

64-bit Machines

How much can we address with 64-bits?

- 16 EiB (2^{64} addresses = $2^4 \times 2^{60}$)

64-bit Machines

How much can we address with 64-bits?

- 16 EiB (2^{64} addresses = $2^4 \times 2^{60}$)
- But I only have 8 GiB of RAM

A Challenge

There is a disconnect:

- Registers: 64-bit values
- Memory: 8-bit values (i.e., **1 byte** values)
 - Each address addresses an 8-bit value in memory
 - Each address points to a 1-byte slot in memory

A Challenge

There is a disconnect:

- Registers: 64-bit values
- Memory: 8-bit values (i.e., **1 byte** values)
 - Each address addresses an 8-bit value in memory
 - Each address points to a 1-byte slot in memory
- How do we store a 64-bit value in an 8-bit spot?

Rules

Rules to break “big values” into bytes (memory)

1. Break it into bytes
2. Store them adjacently
3. Address of the overall value = smallest address of its bytes
4. Order the bytes
 - If parts are ordered (i.e., array), first goes in smallest address
 - Else, hardware implementation gets to pick (!!)
 - Little-endian
 - Big-endian

Ordering Values



Little-endian

- Store the low order part/byte first
- Most hardware today is little-endian

Big-endian


- Store the high order part/byte first

32 bits → 0x 12 34 56 78



Example

Store [0x1234, 0x5678] at address 0xF00



Endianness

Why do we study endianness?

- It is **everywhere**
- It is a source of weird bugs
- Ex: It's likely your computer uses:
 - Little-endian from CPU to memory
 - Big-endian from CPU to network
 - File formats are roughly half and half

Moving up!

Assembly

General principle of all **assembly languages**

- Code (text, not binary!)
- 1 line of code = 1 machine instruction
- One-to-one reversible mapping between binary and assembly
 - We do not need to remember binary encodings!
 - A program will turn text to binary for us!